

**NOTE: TO AVOID ELECTRICAL SHOCK  
PANEL MUST BE MOUNTED INSIDE  
CABINET.**

**PANEL UP ARROW MUST BE  
UP TO OPERATE START RELAY.**

