

BD FREEZER BIN THERMOSTAT ADJUSTMENT INSTRUCTIONS

- 1) Remove the (4) screws inside the Bin that hold the cover.
- 2) Remove the thermostat knob by pulling straight up.
- 3) Remove the two thermostat screws on either side of the knob
- 4) Remove thermostat cover by moving it directly away from the bin.
- 5) Thermostat will be revealed, note plastic end cover. See figure #1.
- 6) Remove the plastic end cover by prying and sliding it with small flat blade screwdriver.
- 7) Turn adjustment screw one to one and half turns clockwise to "warm" the control. See Figure #2.
- 8) Reassemble. Note the knob must engage in the tab sticking up next to the shaft.



Figure #1



Figure #2